



Insert the joystick shaft through the black cone, base and white cone as shown. Once shaft is through white cone, slide E Type Ring from side to lock together.

